FITTING INSTRUCTION Clamp mark in acc. with Cables joining PN Left directional lights Rear fog lights 31 Ground Right directional lights Right side parking lights Stoplights Left side parking lights

This towbar is designed to assembly in following cars:

TOYOTA COROLLA Station Wagon KOMBI (E11) produced since 06.1997 till 12.2001, catalogue no. O17A and is prepared to tow trailers max total weight 1400 kg and max vertical load 75 kg.

From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towbar depends also on correct assembly and correct exploitation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towbar should be install in points described by a car producer.

Assemble instruction

- 1. Disassemble the bumper.
- 2. Disassemble original transport handles (not used any more)
- 3. Put main bar of the towbar (pos. 1) and fix it through holes pos. A using bolts from original handles.
- 4. Through holes pos. B and fish-plate pos. 4 fix by bolts M10x35mm (pos. 5).
- 5. Reassemble the bumper after cut out his small fragments. See supplied template.
- 6. Fix body of the automat and place tow-ball according to supplied instruction. Note! Remember to place socket plate (pos. 3) as shown on the drawing 1.
- 7. Tighten all bolts according to the torque shown in the table.
- 8. Connect electric wires of 7-poles socket according to the instruction of the car. (Recommend to make at authorized service station)
- 9. Complete paint layer damaged during installation.

Torque settings for nuts and bolts (8,8):

 M 8
 25 Nm
 M 10
 55 Nm

 M 12
 85 Nm
 M 14
 135 N

NOTE

After install the towbar you should get adequate note in registration book (at authorised service station). The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km check all bolts and nuts. The ball of towbar must be always kept clear and conserve with a grease.

Towbar accessories:

Pos. Name: Main bar Quantity: 1	Pos. Name: Bolt 8,8 B 5
	Pos. Name: Nut 8 B Guantity: 4 Dim. : M10
Poz. Tow ball (mounting set) SZTUK:1	Pos. Name: Plain washer 7 Quantity: 4 Dim.: Ø 10,5 mm
Pos. Name: Socket plate 3 Ouantity: 1	Pos. Name: Spring washer Ouantity: 4 Dim.: Ø 10,2 mm
Pos. 4 Name: Fisch-plate Quantity: 2	



PPUH AUTO-HAK S.J.

Produkcja Haków Holowniczych Henryk & Zbigniew Nejman 76-200 SŁUPSK ul. Słoneczna 16K tel/fax (059) 8-414-414; 8-414-413 E-mail: office@autohak.com.pl www. autohak.com.pl

Towing hitch (without electrical set)

Class: A50-X Cat. no. O17A

Designed for:

Manufacturer: TOYOTA

Model: COROLLA Station Wagon

Type: **ESTATE** (**E11**)

produced since 06.1997 till 12.2001

Technical data: **D**-value: **7.7kN**

maximum trailer weight: **1400 kg** maximum vertical cup load: **75 kg**

Approval number acc. to regulations EKG/ONZ 55.01: E20-55R-01 1740

Foreword

This towbar is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch.

The vehicle manufacturer's specifications regarding trailer load and max. vertical cup load are decisive for driving, and values for the towing hitch cannot be exceeded.

D-value formula:

Max trailer weight [kg] x Max vehicle weight [kg] $= X \frac{9,81}{1000} = D [kN]$

Template for cut out fragments of the bumper 10 yota Corolla Estate produced since 07.1997 till 07.2001



